

## Lab 3

#### **Inductive Reactance**

# **Objective**

Inductive reactance will be examined in this exercise. In particular, its relationship to inductance and frequency will be investigated, including a plot of inductive reactance versus frequency.

# **Theory Overview**

The current – voltage characteristic of an inductor is unlike that of typical resistors. While resistors show a constant resistance value over a wide range of frequencies, the equivalent ohmic value for an inductor, known as inductive reactance, is directly proportional to frequency. The inductive reactance may be computed via the formula:

 $X_i = 2\pi f L$ 

The magnitude of inductive reactance may be determined experimentally by feeding an inductor a known current, measuring the resulting voltage, and dividing the two, following Ohm's Law. This process may be repeated across a range of frequencies in order to obtain a plot of inductive reactance versus frequency. An AC current source may be approximated by placing a large resistance in series with an AC voltage, the resistance being considerably larger than the maximum reactance expected.


# **Equipment**

- 1. AC Function Generator
- 2. Oscilloscope DMM

### **Components**

- 1 mH actual:
  10 mH actual:
- 3. 10 kΩ actual:\_\_\_\_\_





## **Procedure**

#### 1. Current Source

Using Figure 1 with Vin=10 Vp-p and R=10 k $\Omega$ , and assuming that the reactance of the inductor is much smaller than 10k and can be ignored, determine the circulating current using measured component values and record in Table 1.

#### 2. Measuring Reactance

Build the circuit of Figure 1 using R=10 k $\Omega$ , and L=10 mH. Place one probe across the generator and another across the inductor. Set the generator to a 1000 Hz sine wave and 10Vp-p. Make sure that the Bandwidth Limit of the oscilloscope is engaged for both channels. This will reduce the signal noise and make for more accurate readings.

- 3. Calculate the theoretical value of XL using the measured inductor value and record in Table 2.
- 4. Record the peak-to-peak inductor voltage and record in Table 2.



- 5. Using the source current from Table 1 and the measured inductor voltage, determine the experimental reactance and record it in Table 2. Also compute and record the deviation.
- 6. Repeat steps three through five for the remaining frequencies of Table 2.
- 7. Replace the 10 mH inductor with the 1mH unit and repeat steps two through six, recording results in Table 3.
- 8. Using the data of Tables 2 and 3, create plots of inductive reactance versus frequency.

İsource(p-p)	
--------------	--

Table 1

Frequency	$X_L$ Theory	V <sub>L(p-p)</sub> Exp	X <sub>L</sub> Exp	% Dev
1 k				
2 k			č	
3 k				
4 k				
5 k	3			
6 k				
8 k				
10 k		i to	:	

Table 2



Frequency	X <sub>L</sub> Theory	V <sub>L(p-p)</sub> Exp	Xı Exp	% Dev
10 k				
20 k				
30 k				
40 k				
50 k				
60 k				
80 k				
100 k				

Table 3

# **Questions**

- 1. What is the relationship between inductive reactance and frequency?
- 2. What is the relationship between inductive reactance and inductance?
- 3. If the 10mH trial had been repeated with frequencies 10 times higher than those in Table 2, what effect would that have on the experiment?
- 4. Do the coil resistances have any effect on the plots?